


Android Application "SUPERCAM" for Q-See models:


QSD2316L / QSD2308L / QSDT8DP / QSTD2408 / QSTD2416 / QSD2304L / QSDF8204 / QSTD5304 / All PCI DVR Cards.

Instructions:


Step 1: Go to the "Market" icon on your Android window.




Step 2: Go to Search and type "SuperCam". Click on "INSTALL" to install the program onto your phone.




Step 3: After the installation is finished, you will find the icon for SuperCam on your phone's program list.



Step 4: Click the SuperCam Icon to open the program. Type the server address, (the IP address you use to access your DVR remotely), and your ID and password.



Step 5: Click "Login", you will enter the function interface.



Playback: play back video you have recorded on the phone

Image: check the pictures saved on the phone




Log: check the event log saved on the phone

Server list: the servers you accessed and saved
















Live: remote live view

Settings: the settings on your phone

Information: about the remote DVR and your phone.

Step 6: Click Live to view. The default is camera1. Click  to record video. Click  to capture picture. Click  to enter PTZ mode.



1	Current camera number	2	Camera indicators
	Change cameras		Enter PTZ control
	Snap		Record on your phone
	Two way voice		Open audio
	Full screen		Return
	PTZ up		PTZ down
	PTZ left		PTZ right
	PTZ pauze		Zoom In/Focus In/Iris Add
	Zoom Out/Focus Out/Iris Sub	Preset	Preset
Group	Cruise		