




Accessing From iPhones

At present, the software only supports iPhone os2.2 and above, if phone firmware is lower than this version please upgrade it.

Step1 : Go to the App Store function of iPhone



Step 2: Enable "search"  function to search for "SuperCam", the available programs will be displayed on the top of search box




Step 3: Click SuperCam, enter into "introduce" interface and click FREE", it will change into "INSTALL"



Step 4: Enter into iTunes Store password, click "OK" the below interface will display.


Note: if this is the first time the user is using this feature you will need to enter user ID; if there is no Store account, user need to apply for one.






Step 5: Download and install. After installed, SuperCam icon will display. Click this icon, a function interface will appear as shown below.






Step 6: Click "System setting", to enter into login interface. Enter server's IP address (or domain name), user's ID and password. Click Back to save.



Step 7: Click Live View, the default Cam1 picture will be displayed. Click  to capture picture. Click  to enter PTZ mode.



Step 8: On function interface, click Image View to view the captured picture. Click  or  to switch to next or previous picture. Click  to delete the current picture.



Iphone help



Pic1




Pic2

Pic3

Pic4

Live View

After successfully installing SuperCam software, Click on System Setting (Pic 1), and then enter Server IP address or Domain, User name and password to log in (Pic 2). If you connect successfully, it will go to Live View of CH1 as default (Pic 3), You can choose other desired channels from channel button underneath. Other functions are:

1.  : switch channels
2.  : picture snap.
3.  : ptz control (if server camera is PTZ Camera only) (pic 4)

PTZ Control buttons:










1.  : pan
2. **ZOOM** : Zoom  Zoom in  Zoom out
3. **FOCUS** : Focus.  Long Focus  Short Focus
4. **IRIS** : IRIS  Lighter  Darker
5.  : return to live







Image View



Pic 5



Pic 6

1.  : Previous picture
2.  : Next Picture
3.  : The first Picture
4.  : The last picture
5.  : Delete
6.  : Search Pictures, search page as Pic 6